## RP15211

## INSTALL BUSHING WITH THE <u>SMALLER</u> OUTER DIAMETER TO THE FRONT OF THE CAR, <u>LARGER</u> OUTER DIAMETER TO THE REAR OF THE CAR