

GENERAL FITTING INSTRUCTIONS - RP22145/RP22146

Use this instruction sheet along with any other instructions provided in the package, in addition to the vehicle manufacturer's manual.

CLEAN all paint, rust, and rubber deposits from suspension components. INSPECT for damaged, bent, pitted or worn components and replace before installing this kit.

USE lubricant to adequately GREASE all bushing surfaces designed to pivot (e.g. flange faces and internal bores). DO NOT grease pressed fit surfaces (e.g. outer shell) or outside diameter of bushings. These advanced bushings will never need to be greased after installation.

TIGHTEN all nuts and bolts to manufacturer's specifications with vehicle at normal curb height.

Our kit uses advanced synthetic elastomer bushings for minimal effects on ride quality and maximum effects on handling precision.

CAUTION: This kit must be installed by a qualified mechanic, otherwise an unsafe vehicle and/or personal injury could result.

GENERAL FITTING INSTRUCTIONS - RP22145/RP22146

Use this instruction sheet along with any other instructions provided in the package, in addition to the vehicle manufacturer's manual.

CLEAN all paint, rust, and rubber deposits from suspension components. INSPECT for damaged, bent, pitted or worn components and replace before installing this kit.

USE lubricant to adequately GREASE all bushing surfaces designed to pivot (e.g. flange faces and internal bores). DO NOT grease pressed fit surfaces (e.g. outer shell) or outside diameter of bushings. These advanced bushings will never need to be greased after installation.

TIGHTEN all nuts and bolts to manufacturer's specifications with vehicle at normal curb height.

Our kit uses advanced synthetic elastomer bushings for minimal effects on ride quality and maximum effects on handling precision.

CAUTION: This kit must be installed by a qualified mechanic, otherwise an unsafe vehicle and/or personal injury could result.