

# RP37538 INSTALLATION INSTRUCTIONS

## LEAF SPRING BOLT & BUSHING KIT

1940 NASH AMBASSADOR 8 CABRIOLET (4081)



**FIG.1**

Remove worn pin by pressing out in the direction shown in Fig.1

Press in new pin in the direction shown in Fig.2. Press in until the marked line is flush to the bracket.



**FIG.2**

**MARKED  
LINE**



*STEERING AND SUSPENSION*